

WASHER/DRYER CONTROL PANEL PARTS WASHER/DRYER LAUNDRY SYSTEM


MAYTAG






Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1		Literature Parts	7	W10110033	Knob, Timer	17	3405156	Switch, Rotary
	W10222378	Installation			(Washer)	18	694419	Buzzer, Mini
		Instructions	8		Knob, Control (4)	19	W10113816	Timer, Dryer
	W10196552	Use & Care Guide	9	8521965	Gasket, Console	20	W10124093	Panel, Control
	W10117755	Sheet,	10	8558178	Control,	21	3389453	Bracket, Hinge (2)
		Cycle Feature			C-Version	22		End Cap (RH)
	W10114285	Wire Diagram	11	W10110036	Knob, Timer	23	W10139465	Harness - Dryer
		_			(Dryer)	23B	2154470	Receptacle,
2	3390688	Spacer	12	3400808	Screw,	23C	3395683	Connector
		Foam Pad (2)			10-32 x 5/16			(Motor-Dryer)
3	8528583	Bracket, Control	13	W10112533	Switch, Pressure	24		Clamp, Harness
		(Includes Illus. 2)	14	W10114118	Switch,	25	3390422	Clip, Harness (2)
4	W10124193	Timer, Washer			Temperature	26	8536939	Spring, Clip
5	3389464	Endcap (LH)	15	90767	,			Knob
6	W10112571	Dial, (Washer)	16	W10117655	Switch,	27	W10210799	Clip, Harness (2)
		,	1		Push-To-Start			. ,

DRYER FRONT PANEL AND DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus.		DESCRIPTION
1	3389249	Nut, Push (4)	8	3388229	Retainer, Toe	13	3393008	Screw, 10-16 x 1/2
2	3391902	Switch, Door			Panel (2)	14	3392538	Catch, Door
3	98234	Clip, Ground	9	3387242	Bearing & Seal	15	W10116360	Handle, Door
4	3392547	Panel, Front	10		Screw, 8-18 x 3/8	16	3390902	Clip, Door
5	3390735	Seal, Door	11		Strike, Panel			Hinge (2)
6	3392563	Door, Rear	12		Screw, Door	17	3388958	Panel, Toe
7	3387872	Door, Front			Switch	18		Screw, 8-18 x 1/2
					Mounting (2)	19	3389247	Hinge & Pin,
			13	3393008	Screw. 10-16 x 1/2			Door (2)

DRYER CABINET AND MOTOR PARTS




IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

DRYER CABINET AND MOTOR PARTS For Model: MET3800TW2

Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10121316	Clamp, Motor	13	279393	Screw Kit	25	3387374	Spring, Idler
		Mounting (2)			(For Terminal	26	3389683	Cove, Transition
2	8538266	Motor, Main Drive			Block)			Panel (Black)
		(60 Hz.)	14	W10167612	Wire, Broken	27		Panel, Transition
3	3398948	Wire, Jumper			Belt Switch	28		Top, Dryer
4	3394881	Switch, Broken	15	3389231	Clip, Front	29	693304	Screw & Washer
		Belt			Panel (2)	30		Spacer (2)
5	3388858	Bracket, Motor	16	98234	Clip, Ground	31	3393722	Bracket,
6	3389847	Panel, Rear	17	3391639	Bracket, Bulkhead			Terminal Block
7		Screw, 10-16 x 1/2	18	690997	Washer,	32	3389431	Bumper, Lid Stop
8	3387673	Cover, Terminal			Thrust	33		Nut, Push-In
		Block	19	W10121334	Tri–Ring	34		Screw, 10-16 x 5/8
9	8533974	Screw, Ground	20	3387610	Belt, Drive	35	98129	Screw,
		(10-32 x 1/2)	21	3391087	Pulley, Motor			6-20 x 1-1/16
10		Panel, Side (L.H.)			(60 Hz.)	36	3397659	Block,
		Panel, Side (R.H.)	22	3389332	Bracket, Idler			Terminal
11	8066120	Lever, Snap	23	3390722	Shield-Console	37	3390631	Screw, 10-16 x 3/8
		Switch			To Drum	38	3389420	Bolt, Shoulder
12	279318	Terminal, Tinned	24	3390026	Base, Dryer	39		Pulley, Idler
		& Brass (3)	l		•	40	3394743	Pin, Řoll

DRYER BULKHEAD PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

Illus			Illus			Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	8575324	Shaft, Roller	19	8575325	Shaft, L.H. Thread	39	697366	Plate, Blower
2	90767	Screw, 8-18 x 3/8	20	690997	Tri– Ring	40	3394986	
3		Screw, 10-16 x 1/2	21	8536973	Support, Roller			Screen Door
4	3394984	Door, Lint	22		Screw, 10-16 x 1/2	41	3402841	Lens, Drum Light
		Screen	23		Housing, Outlet	42	3387134	Thermostat,
5	697354	Air Duct Assembly	24		Screw, 8-18 x 1/2			Internal-Bias
6		Seal, Outlet	25		Assembly, Drum	43	487909	Screw, 8-15 x 1/2
		Housing	26		Screw, 8-16 x 1/2	44	8544363	Housing, Blower
7		Seal, Lint Duct	27		Seal, Drum	45	3388909	
8	3934666	Nut (2)	28	3387230	Screw,			Assembly
9	8066086	Drum Hole			10-16 x 13/16			(Includes
		Plug	29	3392258	Wire, Ground			Illus. 7 & 13)
10	3389449	Baffle, Drum (3)			(Sensor)	46	697715	Box, Heater
11	8563748	Pipe, Exhaust	30	3387223	Electrode (Sensor)	47	3977394	Thermal Cutoff
12		Screw, 8-18 x 1/2	31		Seal, Cover Plate			(Includes
13	3391685	Seal, Transition	32	3977373	Bracket, Light			Illus. 48)
		Duct To Lint Duct	33	8566209		48	3390291	Fixed, Thermostat
14	3387749	Element, Heater			Transition Duct	49	3389647	Bracket, Heater
15	279457	Wire Kit (For	34	W10136369	Socket Assembly			Mounting
		Heater Element	35	3390935		50	3403607	Limiter,
		Wiring Harness			Locator			Thermal
		Repair)	36	3406124	Bulb, Light	51	3389644	Screen, Lint
16	W10001120	Nut, Hex (2)	37	697772	Wheel, Blower	52	8299979	Grille, Outlet
17		Bulkhead, Rear	38	3389445	Duct, Transition	53	697557	Bulkhead, Front
18	3387459	Washer, Support			(Includes Illus.	54	8571651	
			l		No.33)			Bulkhead (Upper)


DRYER SUPPORT AND WASHER HARNESS PARTS

For Model: MET3800TW2 (White) WIRING HARNESS PARTS 1B 1D 17.

DRYER SUPPORT AND WASHER HARNESS PARTS

Illus No.	. Part No.	DESCRIPTION
1	W10139637	Harness – Washer
1A	3350130	Plug, 3 Way
1B	3347243	Connector, 5 Way
1C	352089	Block,
		Disconnect – Timer
1D	3350211	Receptacle, 3 Way
1E	62505	
2	3388851	Channel Assembly
		(Left Hand Side)
3	3388850	Channel Assembly
		(Right Hand Side)
4	3390609	Shield, Harness
5	8545438	Hose, Pressure
		Switch
6	2219077	Clip, Harness
7	343641	Screw, 10-16 x 1/2
8	685463	Kit, Grounding
9	8533971	Screw
10	685449	Wire
11	3401144	Connector,
		(PTS Relay)
12	22965	Strap, Grounding
13	3400300	Bolt,
	0500050	5/16–18 x 1/2 (4)
14	8533952	Nut, Hex (4)
15	3394350	Shield, Front
16	3390336	Shield, Thermostat
17	3393008	Screw, 10–16 x 1/2
18	W10210799	Clip, Harness (2)
19	3354925	Connector,
19	3334923	H–Pod
20	3360056	Connector,
20	3300030	Pressure Switch
21		Terminal,
۲ ا	94613	Male
	94614	
22	63523	Protector,
	00020	Harness


WASHER TOP AND LID PARTS



WASHER TOP AND LID PARTS

Illus. No.	Part No.	DESCRIPTION
1	3351652	Lid
2	9724509	Bumper, Lid (2)
3	W10119872	Screw And Washer
4	343641	Screw, 10-16 x 1/2
5	692400	Nut, Push-In (2)
6	3349817	Top
7	357572	Clip, Grounding
8	3354020	Bracket Mounting
9	3350152	Lid Retainer
10	3350828	Clip
11	21258	Hinge, Bearing (2)
12	3356311	Screw And Washer
13	358684	Strike, Lid
14	3350101	Hinge, R.H.
15	3350102	Hinge, L.H.
16	3362952	Dispenser-Bleach
17	3355458	Switch, Lid
18	90016	Clip, Wire (4)
19	W10134768	Locator, Top


WASHER CABINET PARTS




WASHER CABINET PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349770	Clip, Spring	11	9740848	Screw, 8-18 x 1/2	27	3349499	Panel, Front
		Top (2)	12	660975	Plug, Top To	28	303294	Edge, Protector
2	3349768	Bracket, Vacuum			Cabinet (2)	29		Foot, Rear (2)
3	62863	Screw, Mixing	13	8557915	Connector, Hose	30	3350144	Bracket, Lid
		Valve Mounting	14		Clamp, Hose			Switch
4	3350013	Foam	15	3349673	Bracket, Valve	31	8533952	Nut, Hex (2)
5	3979349	Valve, Water	16	387606	Thermister, Inlet	32	352292	Nut, Push-In (2)
		Mixing	17	371503	Clamp, Hose	33	3400300	Screw,
6	370451	Clamp, Hose	18	3350145	Shield, Lid			5/16-18 x 1/2
7	8521954	Hose, Water Inlet			Switch	34	389102	Foot, Front (2)
		(Vacuum Break To	19	3402724	Base, Cabinet	35	3400917	Nut, Jam (2)
		Mixing Valve)	20	3388857	Bracket, Base	36	3349493	Panel, Rear
8	3349455	Panel, Side (2)	21	371507	Clamp, Hose			(Washer)
		(Same Panel	22	3394083	Clip, Front Panel (2)	37	343641	Screw, 10-16 x 1/2
		Used On Left	23		Link, Leveling	38	3349697	Rail, Back
		And Right Side)	24	359364	Clip, Leveling			Тор
9	3350745	•			Mechanism (2)	39	3350135	Spring, Lever
		Panel	25		Clip, Ground			Bracket
10	3353841	Hose, Drain	26	345670	Lock, Top (2)	40	3390608	Shield, Corner Right Rear

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS



MACHINE BASE PARTS



AGITATOR, BASKET AND TUB PARTS For Model: MET3800TW2

AGITATOR, BASKET AND TUB PARTS


Illus No.	. Part No.	DESCRIPTION
1	3350834	Dispenser, Assembly
2	3947410	Cam Driven
2 3 4	3366877	Dog, Agitator (4)
	358237	Screw & Washer
5	387094	Cap, Barrier
6	3349610	Mover, Agitator
		Clutch
7	3351014	Spacer, Thrust
8	3349578	g
9	8528150	
10	3976308	
		Tub Ring
11	3352234	
12	21366	
13	387240	
14	3349292	Tub
15	3349743	Agitator,
40	000440	(Complete)
16	389140	,
17	383727	Gasket, Centerpost Washer
18	3949550	
19	W10072840	
20 21	3363366 3951449	Clamp, Hose (2)
۷۱	3931449	Hose & Clamp Assembly

GEARCASE PARTS

		(VV	hite)			
					1	
·			ر ا			
2		h^{4}	l	IIIa	Dowt	
1 < 1				Illus.	Part	DECODIDATION
1 /	3			No.	No.	DESCRIPTION
1 '						_
ΙĮ			1	1	8532118	Gearcase
15			00	2	285202	(Complete) Cover, Gearcase
1 1	6	+	23 ¦	3	3349985	Seal, Gearcase
1 1			_			Cover
1	limmil !	7	24 j	4	285195	Sealer, Gasket
1			1	5	63320	(.20 Fl. Oz.) (6 ml) Pinion, Spin
1 1	8 — 🗐	Market Market Commission of the Commission of th	25 i	Ü	00020	(Includes Illus. 25)
·				6	356427	Seal, Spin
<u>'</u>	9 🌘		26 ¦	7	200207	Pinion
1 1	10 —	' The state of the	1	7	309307	Shaft, Agitator (Complete)
-	→ •		— ¬!	8	90369	Ring, Retaining (2)
	9 _		1.	9	62677	Retainer, Spring (2)
	11	; ; \$	니 1.	10	62676	Spring, Agitate
l	'' ~ •			11	63273	Gear, Agitate (Includes 15 & 29)
1	12		11	12	62619	Washer, Agitate
1	- 19 h	<u> </u>	<u> </u>			Gear
1	13			13	62580	Cam Follower
1	14		[1]	14	62581	(Includes 14) Cam, Agitate
1				14	02301	(Includes 13)
1			l ₁	15	285509	Shaft, Agitator
i			li.	4.0	00040	(Includes 11 & 29)
1			' 	16	62618	Washer, Cam Thrust
<u> </u>	Ş		- '	17	16018	Bearing, Thrust
<u> </u>	[]					(Includes 18)
1	15 \ 1			18	85529	Ball, Bearing
			- 27 <u> </u>	19	200220	(Includes 17) Bottom and Pinion,
	hand!			19	309230	Gearcase
	YAAA			20	3949116	Block Tab,
1	16	9	- 28 I			Terminal
1	29			21 22	285352	Seal, Thrust Plug Screw, Gearcase
1			1	22	3331014	Cover Mounting (8)
1	8 8	<u> </u>	_20			(10-24 x 3/8)
1 17				23		Ring, Retaining
1 40			1	24	285735	Washer Kit,
¦ 18			. 19 i	25	62570	Thrust Gear, Spin
1			i	26	388253	Neutral Assembly
·			i	27	3349296	Rack, Connecting
·		\	i	28 29		Actuator, Shift Washer,
·	21	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	i	29	300013	Intermediate
1	1000		1			
1			1			
1			!			
1		4				
I		GC	-220 l			
L — ·						

BRAKE AND DRIVE TUBE PARTS

For Model: MET3800TW2 (White)




Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
2 3	356427	Seal, Drive Tube
4	64027	Tube, Basket
		Drive (Includes
		Illus. 3, 4, 5 & 9)
5	64035	
6		Shoe, Brake (2)
7	62703	3,
		Spin Tube
8	3353956	
_		Spring (2)
9	62647	-1 3,
10	3355360	,
	004=40	Spring
11	661516	,
40	00000	Release
12		Sleeve, Cam
13	64194	- ,
14	90368	Cam Ring, Retaining


FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

WATER SYSTEM PARTS



MISCELLANEOUS PARTS



Illus No.	. Part No.	DESCRIPTION
1	W10112404	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose
3	356138	Clamp, Hose
5	3357331	Clamp, Hose (Upper Drain)

OPTIONAL PARTS (NOT INCLUDED)

For Model: MET3800TW2 (White)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

PAINT, PRESSURIZED SPRAY

(12 oz.)

350938 Primer, Gray 350930 White 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

ACCESSORIES

279823 Side Exhaust Kit